

iLOQ S50

User manual



iLOQ S50


Your mobile phone is key and energy source

- No batteries
- Environmentally friendly
- Works offline

[iLOQ webpage: S50](#)



iLOQ S50 Keys



iLOQ S50 Mobile iPhone App
iPhone 7 or later
(minimum iOS13)




iLOQ S50 Mobile Android App
Android 9 or later





Key Fob

Install the app in your mobile phone

When we have created your mobile key, an SMS is sent from iLOQ



- Download the app "iLOQ s50" from App store or Google play
- You will receive the mobile key in a message from iLOQ
- Open the iLOQ registration message and press the link
- To activate the key – enter the activation code from a new message from iLOQ
- Your key is now activated!
- OBS! The link in the message is valid for 120 hours.




[Video: How to start using iLOQ S50 with your iPhone](#)

[Video: How to start using iLOQ S50 with your Android phone](#)


How to unlock the waste containers- IPHONE

1. Open the iLOQ S50 app
2. Tap "use key/ används nyckeln" on the screen. The screen shows the location of the NFC-antenna.
3. Hold the back of the phone (where the NFC antenna is located) directly against the round iLOQ knob by the lid and hold still.
4. When the screen shows a tick the lid is open.
5. Turn the iLOQ knob to the right and then open the lid within 10 seconds
6. Please close the lid after leaving your waste!



How to unlock the waste containers- ANDROID

1. Open the iLOQ S50 app
2. Hold the back of the phone directly against the round iLOQ knob by the lid and hold still. The screen shows where the NFC-antenna is located on your phone. Move your phone according to the instructions.
3. When the screen shows a tick the lid is open.
4. Turn the iLOQ knob to the right and then open the lid within 10 seconds
5. Please close the lid after leaving your waste!



NFC – placement of the antenna

- **Android** 9 or later - NFC needs to be activated in the mobile settings




- **iPhone** 7 or later – NFC is always activated

OBS! It does not work on older iPhones – the antenna is too weak.



More settings and instructions

There are more instructions in the iLOQ app



Tap the gear wheel to adjust how long the lock remains open (max 15 seconds)